

# MANUAL DIMMING

Thorlux Smart luminaires can be manually controlled using a retractive (push to make) switch or the Smart-Remote infra-red handset

## Wall Switch Kit

Any number of retractive switches can be connected to the Motionline to provide group dimming control of the Smart luminaires.


In normal operation each Smart luminaire will automatically adjust its own luminance level to maintain the preset required light level.

When controlled via the switch all the luminaires will initially synchronise to the same lighting level which can then be varied from 100% to 1% (some ballasts are limited to 10%) and off.

Once the area is vacated and the installation has subsequently turned off, the system will revert to automatic mode. Automatic mode can also be reselected by one single momentary press of the switch.

Luminaires can also be re-programmed for absence detection. Use of the switch is required to turn on but if the room is left unoccupied the luminaires will automatically turn off after the pre-determined time.

Any "standard" retractive switch can be used and connected to the Motionline or our ready made modular wiring solution can be selected.



### RANGE

DESCRIPTION	CAT. No.	APPROX. kg
Wall switch kit - modular wiring c/w inline connector	<b>LCM 14010</b>	0.25

## Smart-Remote Infra-red Handset

The Thorlux Smart-Remote can be used to control individual luminaires or the group as a whole. It provides full control with on, off, raise and lower features. The Smart-Remote is supplied with a unique, robust wall mounting bracket. A locking key kit ECO 9724 is available if required.



### RANGE

DESCRIPTION	CAT. No.	APPROX. kg
Smart-Remote	<b>LCM 13479B</b>	0.08
Locking Key Kit	<b>ECO 9724</b>	-